

Matrox Solios eA/XA

Camera Interface Application Note

CIS VCC-G20U20

December 17, 2008

*Basics about the
camera*

Camera Descriptions

- Effective resolution: $1620 \times 1220 \times 8\text{-bit}$ @ 15 fps.
- Analog monochrome video output.
- Progressive scan.
- Internal or external sync.
- Internal or external exposure control.
- 36 MHz pixel clock rate.


Interface Mode

- Continuous
- Pseudo- continuous (External Trigger Operation by pulse width)
- Asynchronous reset (External Trigger Operation by pulse width)

Camera Interface Briefs

Mode 1: Continuous

- $1620 \times 1220 \times 8\text{-bit}$ @ 15 fps.
- Analog monochrome video.
- Matrox Solios eA/XA receiving Sync and video signals from camera.
- DCF used: [VCCG20U20_1620x1220Con.DCF](#)



Mode 2: Pseudo-continuous

- Up to $1620 \times 1220 \times 8\text{-bit}$.
- Analog monochrome video
- Matrox Solios eA/XA sending EXPOSURE1 (TRIGGER IN) signal to camera to initiate and control the exposure.
- Matrox Solios eA/XA receiving Sync and video signals from camera.
- DCF used: [VCCG20U20_1620x1220Pcon.DCF](#)

Continued...

*Mode of operations as
per Matrox Imaging (in
parentheses as per
camera manufacturer)*

*Basics about the
interface modes*

Matrox Solios eA/XA

Camera Interface Application Note


CIS VCC-G20U20

December 17, 2008

Basics about the
interface modes


Camera Interface Briefs

Mode 2: Pseudo-continuous



Mode 3: Asynchronous reset

- Up to $1620 \times 1220 \times 8$ -bit.
- Analog monochrome video
- Matrox Solios eA/XA receiving external trigger signal.
- Matrox Solios eA/XA sending EXPOSURE1 (TRIGGER IN) signal to camera to initiate and control the exposure.
- Matrox Solios eA/XA receiving Sync and video signals from camera.
- DCF used: [VCCG20U20_1620x1220Async.DCF](#)



Specifics about the
interface modes

Camera Interface Details

Mode 1: Continuous

- **Frame rate:** Matrox Solios eA/XA receives the continuous video from the camera at 15 frames per second.
- **Exposure time:** Exposure time is inversely proportionate to the frame rate (no shutter) or determined by the shutter setting. Refer to the camera manual for more information.

Matrox Solios eA/XA

Camera Interface Application Note

CIS VCC-G20U20

December 17, 2008

Specifics about the
interface modes

Camera Interface Details (cont.)

Mode 1: Continuous

- **Camera switch settings:** Refer to the camera manual for additional information. External and internal switches for this mode should be set as follows:

External DIP Switch settings									
1	2	3	4	5	6	7	8	9	10
OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF
Internal Sync. Mode Switch: Set to INTERNAL									

Mode 2: Pseudo-continuous

- **Frame rate:** The Frame Rate is determined by the frequency of Timer1. The maximum possible frame rate is dependent on the exposure time as well as the camera's frame readout period.
- **Exposure time:** The width (active duration) of the EXPOSURE1 (TRIGGER IN) signal is the exposure time, which can be modified in the DCF using Matrox Intellicam or with the MIL MdigControl() function. Consult the respective manual for more information.
- **Camera settings:** Refer to the camera manual for additional information. Switches for this mode should be set as follows:

External DIP Switch settings									
1	2	3	4	5	6	7	8	9	10
OFF	OFF	OFF	ON	OFF	OFF	OFF	OFF	OFF	OFF
Internal Sync. Mode Switch: Set to EXTERNAL									

Mode 3: Asynchronous Reset

- **Frame rate:** The frame rate is determined by the frequency of the external trigger signal. The maximum possible frame rate is dependent on the exposure time as well as the camera's frame readout period.
- **Exposure time:** The width (active duration) of the EXPOSURE1 (TRIGGER IN) signal is the exposure time, which can be modified in the DCF using Matrox Intellicam or with the MIL MdigControl() function. Consult the respective manual for more information.
- **Camera settings:** Refer to *Mode 2: Pseudo-continuous*.

Matrox Solios eA/XA

Camera Interface Application Note

CIS VCC-G20U20

December 17, 2008

Cabling details for the
interface modes

Cabling Requirements

Mode 1: Continuous

- **Cable and Connection:** DVI-TO-8BNC/O (open ended) cable required for video and synchronization signals. The connections between the camera's 12-pin connector and the DVI connector of the Matrox Solios eA/XA are as follows:

Matrox Solios eA/XA (DVI analog input connector-0)		CIS VCC-G20U20 (12-pin connector)	
Pin name	Pin no.	Pin name	Pin no.
CH0_INPUTA	C1	VIDEO	04
GROUND	C5	VIDEO OUT GND	03

Mode 2: Pseudo-continuous

- **Cable and Connection:** DVI-TO-8BNC/O (open ended) cable required for video and synchronization signals. The connections between the camera's 12-pin connector and the DVI connector of the Matrox Solios eA/XA are as follows:

Matrox Solios eA/XA (DVI analog input connector-0)		CIS VCC-G20U20 (12-pin connector)	
Pin name	Pin no.	Pin name	Pin no.
CH0_INPUTA	C1	VIDEO	04
GROUND	C5	VIDEO OUT GND	03
P0_TTL_AUX (EXP_OUT)	23	TRIGGER IN	11
GROUND	11	TRIGGER IN GND	12

Mode 3: Asynchronous reset

- **Cable and Connection:** DVI-TO-8BNC/O (open end) cable required for video signal. The connection between the 12-pin connector of the camera and the Matrox Solios are as follow:

Matrox Solios eA/XA (DVI analog input connector-0)		CIS VCC-G20U20 (12-pin connector)	
Pin name	Pin no.	Pin name	Pin no.
CH0_INPUTA	C1	VIDEO	04
GROUND	C5	VIDEO OUT GND	03
P0_TTL_AUX (EXP_OUT)	23	TRIG IN	11
GROUND	11	TRIG IN GND	12

Matrox Solios eA/XA

Camera Interface Application Note

CIS VCC-G20U20

December 17, 2008

*Cabling details for the
interface modes*

Cabling Requirements (cont.)

Mode 3: Asynchronous reset

- **External trigger:** External trigger should be connected to the OPTO TRIG input of the 9-pin connector (pins 7 and 2) on the external trigger input connector 1 (cable adapter board).

External trigger input

(9-pin connector)

External Trigger Source

OPTO TRIG+	07	←	SIGNAL	--
OPTO TRIG-	02	←	GND	--

The DCFs mentioned in this application note are also attached (embedded) to this PDF file – use the Adobe Reader's View File Attachment to access the DCF files. The information furnished by Matrox Electronics System, Ltd. is believed to be accurate and reliable. Please verify all interface connections with camera documentation or manual. Contact your local sales representative or Matrox Sales office or Matrox Imaging Applications at 514-822-6061 for assistance. © Matrox Electronic Systems Ltd, 2008-2011.

Matrox Electronic Systems Ltd.

1055 St. Regis Blvd.
Dorval, Quebec H9P 2T4
Canada
Tel: (514) 685-2630
Fax: (514) 822-6273

SOL-CID-086

