

Matrox Odyssey eCL/XCL

Camera Interface Application Note

Photonfocus MV-D1024-80-CL-8

October 5, 2006

*Basics about the
camera*

Camera Descriptions

- Effective resolution: $1024 \times 1024 \times 8\text{-bit}$ @ 75 fps.
- Camera Link BASE interface (8-bit, dual tap).
- Progressive scan.
- Internal sync.
- Internal exposure control.
- 40 MHz pixel clock rate.


Interface Mode

- Continuous (Free Running)
- Pseudo-continuous (Trigger)
- Asynchronous reset (Trigger)

Camera Interface Briefs

Mode 1: Continuous

- $1024 \times 1024 \times 8\text{-bit}$ @ 75 fps.
- Camera Link BASE interface (8-bit, dual tap).
- Matrox Odyssey eCL/XCL receiving LVAL, FVAL, PIXEL CLOCK (CLK @ 40 MHz) and video from camera.
- DCF used: [MVD102480CL8_1024x1024_8bit2tapCon.DCF](#)



Mode 2: Pseudo-continuous

- $1024 \times 1024 \times 8\text{-bit}$.
- Camera Link BASE interface (8-bit, dual tap).
- Matrox Odyssey eCL/XCL sending EXPOSURE1 (CC1) signal to camera to initiate and control the exposure.
- Matrox Odyssey eCL/XCL receiving LVAL, FVAL, PIXEL CLOCK (CLK @ 40 MHz) and video from camera.
- DCF used: [MVD102480CL8_1024x1024_8bit2tapPcon.DCF](#)

Continued...

*Mode of operations as
per Matrox Imaging (in
parentheses as per
camera manufacturer)*

*Basics about the
interface modes*

Matrox Odyssey eCL/XCL

Camera Interface Application Note


Photonfocus MV-D1024-80-CL-8

October 5, 2006

Basics about the
interface modes


Camera Interface Briefs (cont.)

Mode 2: Pseudo-continuous



Mode 3: Asynchronous reset

- 1024 × 1024 × 8-bit.
- Camera Link BASE interface (8-bit, dual tap).
- Matrox Odyssey eCL/XCL receiving external trigger signal.
- Matrox Odyssey eCL/XCL sending EXPOSURE1 (CC1) signal to camera to initiate and control the exposure.
- Matrox Odyssey eCL/XCL receiving LVAL, FVAL, PIXEL CLOCK (CLK @ 40 MHz) and video from camera.
- DCF used: [MVD102480CL8_1024x1024_8bit2tapAsync.DCF](#)



Matrox Odyssey eCL/XCL

Camera Interface Application Note

Photonfocus MV-D1024-80-CL-8

October 5, 2006

Specifics about the
interface modes

Camera Interface Details

Mode 1: Continuous

- **Frame rate:** Matrox Odyssey eCL/XCL receives the continuous video from the camera at 75 frames per second. To increase the frame rate, reduce exposure time in the PhotonFocus PFRemote Camera Configuration utility (PFRemote.EXE).
- **Exposure time:** Exposure time is determined by the **Exposure Time Field** setting in the PFRemote utility. Refer to the camera manual for more information.
- **Camera settings:** The camera mode is set to the following setting in the PFRemote utility. Refer to the camera manual for more information.

Mode	Setting
Trigger	Free Running
Output	8-bit
Constant Frame Rate	unchecked

Mode 2: Pseudo-continuous

- **Frame rate:** The frame rate is determined by the frequency of the EXPOSURE1 (CC1) signal.
- **Exposure time:** The EXPOSURE1 (CC1) signal active duration (high to low) initiates and controls the camera's internal exposure time. To modify the exposure time, in Matrox Intellicam change the **Timer 1** value in the DCF or use the MIL MdigControl function. Refer to the MIL on-line Help for more information.
- **Camera settings:** The camera mode is set to the following setting in the PFRemote utility. Refer to the camera manual for more information.

Mode	Setting
Trigger	External Trigger
Output	8-bit
SYNC Pulse Active High	checked
Combined trigger/exposure	checked
Constant Frame Rate	unchecked

Matrox Odyssey eCL/XCL

Camera Interface Application Note

Photonfocus MV-D1024-80-CL-8 October 5, 2006

*Specifics about the
interface modes*

Camera Interface Details (cont.)

Mode 3: Asynchronous Reset

- **Frame rate:** The frame rate is determined by the frequency of the external trigger signal. The period between the external trigger signals must be larger than the frame readout period and the exposure time.
- **Exposure time:** Refer to Mode 2: Pseudo-continuous.
- **Camera settings:** Refer to Mode 2: Pseudo-continuous.

*Cabling details for the
interface modes*

Cabling Requirements

Mode 1 and 2: Continuous and Pseudo-continuous

- **Cable and Connection:** Standard Camera Link cable.

Mode 2: Asynchronous reset

- **Cable and Connection:** Standard Camera Link.
- **External trigger:** External trigger should be connected to the OPTO TRIG input of the 9-pin connector (pins 7 and 2) on the Expanded I/O adapter bracket.

EXPANDED I/O BRACKET (9-pin connector)

			External Trigger Source	
OPTOTRIG +	07	←	SIGNAL	--
OPTOTRIG -	02	←	GROUND	--

The DCFs mentioned in this application note are also attached (embedded) to this PDF file – use the Adobe Reader's View File Attachment to access the DCF files. The information furnished by Matrox Electronic Systems, Ltd. is believed to be accurate and reliable. Please verify all interface connections with camera documentation or manual. Contact your local sales representative or Matrox Sales office or Matrox Imaging Applications at 514-822-6061 for assistance. © Matrox Electronic Systems Ltd, 2006-2011.

Matrox Electronic Systems Ltd.

1055 St. Regis Blvd.
Dorval, Quebec H9P 2T4
Canada
Tel: (514) 685-2630
Fax: (514) 822-6273
ODY-CID-166

