BASLER-MVC L104-1K

GENESI



GENESIS

BASLER-MVC L104-1K

Camera	Mode 1: Fixed line scan rate mode			
Interface Details	• Matrox Genesis sends the periodic EXPOSURE1 (EXSYNC) signal to the camera; camera awaits the rising edge of EXPOSURE1 (EXSYNC) signal and initiates line readout.			
	• Line rate: The EXPOSURE1 (EXSYNC) frequency determines the line rate of the camera. The EXPOSURE1 (EXSYNC) period is currently set to 8000 pixels. At a 28.636 MHz crystal clock rate, the line rate is 3.6 kHz.			
	 Exposure time: There are three modes of exposure time control, which can be selected by programming the EXPOSURE menu tab located in the BASLER Configuration Tool L1x0 (refer to BASLER User Manual for more information). Edge controlled mode- Exposure time is the period between the rising edges of the EXPOSURE1 (EXSYNC) signal. To change the exposure time, modify the active and inactive periods of the EXPOSURE1 (EXSYNC) signal in the DCF. Programmable mode- Exposure time is controlled through the BASLER Configuration Tool L1x0. Level controlled mode- Exposure time is during the inactive period of EXPOSURE1 (EXSYNC) signal. To change the exposure time, modify the next falling edge of the EXPOSURE1 (EXSYNC) signal. To change the exposure time, modify the next falling edge of the EXPOSURE1 (EXSYNC) signal. To change the exposure time, modify the next falling edge of the EXPOSURE1 (EXSYNC) signal. To change the exposure time, modify the next falling edge of the EXPOSURE1 (EXSYNC) signal. To change the exposure time, modify the next falling edge of the EXPOSURE1 (EXSYNC) signal. 			
	 EXPOSURE1 (EXSYNC) signal in the DCF. For Edge-controlled mode and Level controlled mode, the width and deployment time of EXPOSURE1 (EXSYNC) signal can be modified in the DCF using Matrox Intellicam, Genesis Native Library function imCamControl() or with the MIL digitizer control function MdigControl(). Refer to the appropriate manual or user guide for additional information. 			
	• Maximum/minimum exposure time: Since the Matrox Genesis timer is 16-bit wide, the maximum exposure time is calculated to be $65536/28.636$ MHz = 2.29 ms. The maximum line rate of the camera is 61.035 kHz, therefore the minimum exposure time is 32.77 ms.			
	• Smallest exposure time increment: The crystal clock is the reference clock (28.636 MHz) that the exposure time is being set by. The smallest increment of exposure time is 34.9 ns.			
	Mode 2: Variable line scan rate with variable frame size			
	• Once it has received the periodic external line trigger signal, Matrox Genesis sends the EXPOSURE1 (EXSYNC) signal to the camera; the camera awaits the rising edge of the EXPOSURE1 (EXSYNC) signal and initiates line readout. Once Matrox Genesis has received the external frame trigger signal, it captures lines only when trigger is active.			
	• Line rate: The line rate is variable and controlled by the frequency of the external trigger signal.			
	• Virtual Frame size: The number of lines per virtual frame is determined by external frame trigger period. The maximum number of lines per virtual frame is 1700.			
	• Exposure time : Since the EXPOSURE1 (EXSYNC) signal is controlled by the ext. trigger signal, the time between the rising edges of the external trigger signal is the exposure time.			
	• Maximum/minimum exposure time: The maximum exposure time is dependent on the maximum possible external line trigger period. The maximum line rate of the camera is 61.035 kHz, therefore the minimum exposure time is 32.77 ms.			
	• Smallest exposure time increment: Same as in Mode 1.			

BASLER-MVC L104-1K

Cabling Requirements	 Mode 1: Fixed line scan rate DBHD100-TO-OPEN cable and GEN/DIG/BRD/L/_ board required for digital data, synchronization and control signals. Connections between the 44-pin HD SUB connector of the camera and the 100-pin 						
	• Connections between the 44-pin HD SUB connector of the camera and the 100-pin connector of the GEN/DIG/BRD/L/_ are as follows:						
	BASLER L104-1K		 	GEN-DIG-BRD/L/_			
	(44-pin HD SUB con	nector)		(100-pin connector)			
	DOUTO	01	\rightarrow	DATA, INPUT, 0+	01		
	DOUT1	02	\rightarrow	DATA, INPUT, 1+	03		
	DOUT2	03	\rightarrow	DATA, INPUT, 2+	05		
	DOUT3	04	\rightarrow	DATA, INPUT, 3+	07		
	DOUT4	05	\rightarrow	DATA, INPUT, 4+	09		
	DOUT5	06	\rightarrow	DATA, INPUT, 5+	11		
	DOUT6	07	\rightarrow	DATA, INPUT, 6+	13		
	DOUT7	08	\rightarrow	DATA, INPUT, 7+	15		
	DOUT8	09	\rightarrow	DATA, INPUT, 8+	17		
	DOUT9	10	\rightarrow	DATA, INPUT, 9+	19		
	DOUT10	11	\rightarrow	DATA, INPUT, 10+	21		
	DOUT11	12	\rightarrow	DATA, INPUT, 11+	23		
	DOUT12	13	\rightarrow	DATA, INPUT, 12+	25		
	DOUT13	14	\rightarrow	DATA, INPUT, 13+	27		
	DOUT14	15	\rightarrow	DATA, INPUT, 14+	29		
	DOUT15	31	\rightarrow	DATA, INPUT, 15+	31		
	/DOUT0	16	\rightarrow	DATA, INPUT, 0-	02		
	/DOUT1	17	\rightarrow	DATA, INPUT, 1-	04		
	/DOUT2	18	\rightarrow	DATA, INPUT, 2-	06		
	/DOUT3	19	\rightarrow	DATA, INPUT, 3-	08		
	/DOUT4	20	\rightarrow	DATA, INPUT, 4-	10		
	/DOUT5	21	\rightarrow	DATA, INPUT, 5-	12		
	/DOUT6	22	\rightarrow	DATA, INPUT, 6-	14		
	/DOUT7	23	\rightarrow	DATA, INPUT, 7-	16		
	/DOUT8	24	\rightarrow	DATA, INPUT, 8-	18		
	/DOUT9	25	\rightarrow	DATA, INPUT, 9-	20		
	/DOUT10	26	\rightarrow	DATA, INPUT, 10-	22		
	/DOUT11	27	\rightarrow	DATA, INPUT, 11-	24		
	/DOUT12	28	\rightarrow	DATA, INPUT, 12-	26		
	/DOUT13	29	\rightarrow	DATA, INPUT, 13-	28		
	/DOUT14	30	\rightarrow	DATA, INPUT, 14-	30		
	/DOUT15	32	\rightarrow	DATA, INPUT, 15-	32		
	continued						

BASLER-MVC L104-1K

Cabling	BASLER L104-1K			GEN-DIG-BRD/L/_	
Requirements (continued)	(44-pin HD SUB connector)			(100-pin connector)	
(continued)	LVAL	33	\rightarrow	HSYNC, INPUT,+	33
	/LVAL	34	\rightarrow	HSYNC, INPUT,-	34
	PIXEL CLOCK	35	\rightarrow	CLOCK, INPUT, +	39
	/PIXEL CLOCK	36	\rightarrow	CLOCK, INPUT, -	40
	EXSYNC	37	\leftarrow	EXPOSURE1, OUTPUT, +	95
	/EXSYNC	38	\leftarrow	EXPOSURE1, OUTPUT, -	96
	GND	43		GROUND	37
	GND	44		GROUND	38
	 DBHD100-TO-OPEN cable synchronization and control All connections between the connector of the GEN/DIG/E jumpers, and additions: BASLER L104-1K (44-pin HD SUB connector) EXSYNC /EXSYNC GND GND The follow jumper connection GEN/DIG/BRD/L/_ board: 	signals. 44-pin HD SI 3RD/L/_ are a 37 38 43 44 ons are require EXPOSU	JB con s in Mo	GEN-DIG-BRD/L/_ (100-pin connector) EXPOSURE1, OUTPUT, + EXPOSURE1, OUTPUT, - GROUND GROUND e 100-pin connector of the DIG-BRD/L/_ ne Pin no. UTPUT, + 97 UTPUT, - 98 + 35	100-pin
	continued				

BASLER-MVC L104-1K

Cabling Requirements	• Connections between the external hardware trigger (frame and line) and the 100-pin connector of the GEN/DIG/BRD/L/_ are as follow:			
(continued)	External Hardware Trigger	GEN-DIG-BRD/L/_	_	
		Pin name	Pin no.	
	RS-422 Frame Trigger +► US	SER, INPUT, 0+	41	
	RS-422 Frame Trigger US	SER, INPUT, 0-	42	
	► US	SER, INPUT, 1+	43	
	L► US	SER, INPUT, 1-	44	
	RS-422 Line Trigger +► TR	RIGGER, INPUT, +	47	
		RIGGER, INPUT, -	48	

The DCF(s) mentioned in this application note can be found on the MIL and Native Library CD, or our FTP site (ftp.matrox.com). The information furnished by Matrox Electronics System, Ltd. is believed to be accurate and reliable. Please verify all interface connections with camera documentation or manual. Contact your local sales representative or Matrox Sales office or Imaging Applications at 514-822-6061 for assistance.

Corporate headquarters:

Canada and U.S.A.

Matrox Electronic Systems Ltd. 1055 St. Regis Blvd. Dorval, Quebec H9P 2T4 Canada Tel: (514) 685-2630 Fax: (514) 822-6273

