

# MATROX GENESIS CAMERA INTERFACE APPLICATION NOTE

## QIMAGING PMI 1400

MAY 11, 2001

Basics about the camera

Mode of operations as per Matrox Imaging (in parentheses as per camera manufacturer)

Basics about the interface modes

Specifics about the interface modes

### Camera Descriptions

- 1317 × 1035 × 12-bit @ up to 12.5 fps.
- Single channel RS-422 digital video output.
- Progressive scan.
- External exposure control.
- 8 MHz pixel clock rate (maximum).


### Interface Mode

- Control (high resolution)

### Camera Interface Briefs

#### Mode: Control (high resolution)

- 1308 × 1024 × 12-bit @ 2 fps.
- Single channel RS-422 digital video.
- Progressive scan.
- Matrox Genesis sending EXPOSURE1 (EXPOSE) signal to camera.
- Matrox Genesis receiving HSYNC (LINE ENABLE), VSYNC (FRAME ENABLE), PIXEL CLOCK (PIXEL STROBE) and video signals from camera.
- DCF used: [PMI1400.DCF](#) (Created for XILLIX PMI 1400)



\*Matrox Genesis main board with grab module  
\*\*Matrox RS-422 digital data input board

### Camera Interface Details

#### Mode: Control (high resolution)

- **Frame rate:** The frame rate is determined by the frequency of the periodic EXPOSURE1 (EXPOSE) signal. For this DCF the maximum rate equals **2 fps**.
- **Exposure time:** The width (rising edge to falling edge) of the EXPOSURE1 (EXPOSE) signal is the exposure time. The default exposure time is equal to **0.41 seconds**. The exposure time can be modified in the DCF using Matrox Intellacam, Genesis Native Library (GNL) imCamControl() or with the MIL MdigControl() function. Consult the respective manual for more information.


# MATROX GENESIS CAMERA INTERFACE APPLICATION NOTE QIMAGING PMI 1400

MAY 11, 2001

Specifics about the  
interface modes

## Camera Interface Details (continued)

- Timing diagram:



Cabling details for this  
interface mode

## Cabling Requirements

### Mode: Control (high resolution)

- **Cable:** DBHD100-TO-OPEN (open ended) cable required for digital data, synchronization and control signals.
- **Connection:** Connections between the 50-pin connector of the camera and the 100-pin connector of the Matrox Genesis are as follows:

QIMAGING PMI 1400 (50-pin connector)		Matrox Genesis (100-pin connector)	
Pin name	Pin no.	Pin name	Pin no.
EXPOSE +	02	←	EXPOSURE1, OUTPUT, + 95
EXPOSE -	27	←	EXPOSURE1, OUTPUT, - 96
PIXEL STROBE +	04	→	CLOCK, INPUT, + 39
PIXEL STROBE -	29	→	CLOCK, INPUT, - 40
FRAME ENABLE +	06	→	VSYNC, INPUT, + 35
FRAME ENABLE -	31	→	VSYNC, INPUT, - 36
LINE ENABLE +	07	→	HSYNC, INPUT, + 33
LINE ENABLE -	32	→	HSYNC, INPUT, - 34
GND	08	→	GROUND 37
GND	33	→	GROUND 38
MODE CONTROL 3 +	09	←	USER, OUTPUT, 0 + 91
MODE CONTROL 3 -	34	←	USER, OUTPUT, 0 - 92
MODE CONTROL 1 +	11	←	USER, OUTPUT, 1 + 93
MODE CONTROL 1 -	36	←	USER, OUTPUT, 1 - 94
DATA 12 (MSB) +	13	→	DATA, INPUT, 11+ 23
DATA 12 -	38	→	DATA, INPUT, 11- 24
DATA 11 +	14	→	DATA, INPUT, 10+ 21
DATA 11 -	39	→	DATA, INPUT, 10- 22
DATA 10 +	15	→	DATA, INPUT, 9+ 19
DATA 10 -	40	→	DATA, INPUT, 9- 20

CONTINUED...

# MATROX GENESIS CAMERA INTERFACE APPLICATION NOTE QIMAGING PMI 1400

MAY 11, 2001

Cabling details for this  
interface mode

## Cabling Requirements (continued)

QIMAGING PMI 4200 (50-pin connector)		Matrox Genesis (100-pin connector)	
Pin name	Pin no.	Pin name	Pin no.
DATA 9 +	16	→	DATA, INPUT, 8+
DATA 9 -	41	→	DATA, INPUT, 8-
DATA 8 +	17	→	DATA, INPUT, 7+
DATA 8 -	42	→	DATA, INPUT, 7-
DATA 7 +	18	→	DATA, INPUT, 6+
DATA 7 -	43	→	DATA, INPUT, 6-
DATA 6 +	19	→	DATA, INPUT, 5+
DATA 6 -	44	→	DATA, INPUT, 5-
DATA 5 +	20	→	DATA, INPUT, 4+
DATA 5 -	45	→	DATA, INPUT, 4-
DATA 4 +	21	→	DATA, INPUT, 3+
DATA 4 -	46	→	DATA, INPUT, 3-
DATA 3 +	22	→	DATA, INPUT, 2+
DATA 3 -	47	→	DATA, INPUT, 2-
DATA 2 +	23	→	DATA, INPUT, 1+
DATA 2 -	48	→	DATA, INPUT, 1-
DATA 1 (LSB) +	24	→	DATA, INPUT, 0+
DATA 1 (LSB) -	49	→	DATA, INPUT, 0-
GND	25	→	GROUND

The DCF(s) mentioned in this application note can be found on the MIL and Native Library CD, or our FTP site ([ftp.matrox.com](http://ftp.matrox.com)). The information furnished by Matrox Electronics System, Ltd. is believed to be accurate and reliable. Please verify all interface connections with camera documentation or manual. Contact your local sales representative or Matrox Sales office or Matrox Imaging Applications at 514-822-6061 for assistance.

### Corporate headquarters:

Canada and U.S.A.

Matrox Electronic Systems Ltd.  
1055 St. Regis Blvd.  
Dorval, Quebec H9P 2T4  
Canada  
Tel: (514) 685-2630  
Fax: (514) 822-6273

